TITAN EQUIPMENT

BUILT FOR LIFE'S CRITICAL WORK.

Folding Dressing Tables

Care & Owner Reference Manual

TITAN EQUIPMENT | TABLES



TECHNICAL REVIEW DRAFT

Model identification, inspection, care, service records and related TITAN families. This review edition does not replace original model-specific operating instructions or release the equipment for use.

Models: AME-DT-STD, AME-DT-XL

1-888-792-9315 | service@mymortuarycooler.com

TITAN-DT-REF • Rev A • October 30, 2026

Read this before using the reference

Identify the equipment first
Match the model, serial number, revision, fitted wheels, controls and order configuration to the actual equipment. Product names and similar appearance do not establish equal load limits, parts fit or operation.

Separate catalog facts from operating approval
Published catalog figures in this review are reference data, not engineering certification. Original assembly, lock/release, loading, adjustment, folding and service instructions still require model-specific verification. Keep this draft with, not instead of, the approved instructions.

Training and control
Only personnel trained for the specific equipment and task should use it. The facility must determine its staffing, transfer plan, infection-control procedure, route and emergency response. No universal one-person technique or staffing count is established here.

What this edition contains
Model sheets; preparation and inspection guidance; operating-document checkpoints; cleaning and storage guidance; service records; related TITAN families and accessory links. Church-truck finish and drape charts are included in the church-truck edition.

Release status
This edition is prepared for technical and owner review. Existing equipment-document release holds remain in place. It does not authorize an unverified load, accessory, vehicle restraint, slope, lubricant or repair method.

Model identification & specifications

AME-DT-STD

Top: 77 × 26 × 0.75 inches

Working height: 34 inches, fixed

Published rated load: 600 lb per table

Table weight: 68 lb per table

Casters: Four swivel casters with foot locks

Frame: Folding frame with lock mechanism

Folded dimensions: 59 × 26 × 13 inches



Model-specific boundary: A laminated dressing surface is not a draining stainless embalming surface. Do not substitute the stainless-table cleaning or wet-room workflow. Confirm the fitted folding-lock sequence before use.

Catalog reference: https://www.mymortuarycooler.com/products/single-folding-mortuary-dressing-table

AME-DT-XL

Top: 77 × 32 × 0.75 inches

Working height: 34 inches, fixed

Published rated load: 600 lb per table

Table weight: 68 lb per table

Casters: Four swivel casters with foot locks

Frame: Folding frame with lock mechanism



Model-specific boundary: The XL top is wider, not higher-capacity. A complete XL folded envelope is not verified in the present source; do not reuse the Standard folded dimensions.

Catalog reference: https://www.mymortuarycooler.com/products/oversized-width-folding-dressing-table-single-table

Before-use inspection & readiness

Identification and condition

Confirm the model label and applicable load rating are legible. Check frame members, joints, fasteners, contact surfaces and fitted accessories for missing parts, looseness, bends, cracks, corrosion or other damage.

Wheels and brakes

Check fitted wheels, caster attachment and braking components for damage, contamination and free movement using the actual model's approved inspection method. Brakes are positioning aids, not permission to leave an unstable or unattended load.

Support and lock condition

Check the actual model's locks, retaining devices, handles and support points. Do not use equipment whose lock engagement is uncertain or whose controls bind, drift or release unexpectedly. Never put hands into folding or scissor pinch points.

Laminated top

Inspect the top, edges, seams and attachment points for swelling, delamination, damage and fluid penetration. Keep the table out of wet storage; a wider XL top does not raise the published load rating.

Route and working area

Prepare a clear route and firm, level working area; identify thresholds, floor defects, door clearances and wet surfaces. No slope rating or all-terrain approval is established by this reference.

Stop-use rule

If any check fails, remove the equipment from service, label it clearly and contact support with the exact model and serial number. Do not attempt a loaded demonstration to prove a suspect mechanism is safe.

Setup, movement & document checkpoints

Before unfolding

Confirm the exact AME-DT-STD or AME-DT-XL folding-lock procedure. Set up without a load and keep fingers clear of crossing frame members. Do not infer lock engagement from a photograph.

Before loading

Confirm the fixed 34-inch working height, frame-lock condition, caster condition and receiving surface. Plan a controlled transfer with suitable trained assistance; this is not a hydraulic height-adjustable platform.

During preparation

Keep the load supported within the top footprint and the equipment's published rating. Do not use the top as a step, seat or wet-room substitute. Keep liquids out of the laminated top seams.

Before storage

Remove the load and accessories, clean and dry the table, then use the approved folding method. Confirm the actual folded clearance; the Standard dimensions do not establish the XL envelope.

Instructions still required

Original model-specific warnings, control identification, locking/unlocking sequence, load distribution limits, adjustment/loading/folding sequence, staffing requirements, maintenance schedule and authorized service procedures.

Cleaning, storage & maintenance

After each use

The current dressing-table warranty excludes top coverage for wet environments, including coolers, garages and high-humidity storage. Keep the laminated top and seams dry after approved cleaning. Do not flood, soak or pressure-wash the table. Confirm cleaner/disinfectant compatibility with the actual top and finish.

Disinfection

Follow the selected disinfectant label for dilution, application and contact time, and the equipment's verified compatibility instructions. Cleaning/disinfection is not a claim of sterilization. Follow the facility's exposure-control and PPE procedures.

Inspection records

Record date, model/serial, findings, corrective action and reviewer. Before-use checks do not replace the manufacturer's periodic service schedule. Obtain that schedule rather than inventing a monthly/annual interval.

Maintenance and repairs

For equipment, use only verified model-specific parts and approved repair procedures. For drapes, obtain textile-specific repair or replacement approval; do not add attachment holes or unapproved reinforcement. Do not modify the truck, bypass locks or substitute attachment hardware by assumption.

Storage and return to service

Store dry and protected in the approved stable configuration. Keep service access and exits clear. After repair, require documented authorized inspection and release; a cleaning entry alone is not a safe-use approval.

Disinfecting & lubricating

Prepare and separate the tasks

Follow facility exposure-control procedures and the required protective equipment. Remove the equipment from use for cleaning or service. Remove visible soil using the approved material-compatible cleaning method before disinfection. Decontaminate equipment before mechanical servicing; cleaning, disinfection and lubrication are different tasks.

Disinfect using an approved product

Confirm compatibility with every treated material and follow the disinfectant label for dilution, application, required wet contact time, rinsing where directed and drying. Do not mix chemicals or shorten contact time. Do not assume bleach, alcohol, iodine, phenolic products, steam or immersion is suitable for every TITAN item. Cleaning or disinfection is not a claim of sterilization.

Lubricate only verified service points

Use only the lubricant, amount, points and interval confirmed for the supplied model and revision. If that information is missing, obtain it from support before applying lubricant. Do not blanket-spray the frame or assume that locks, brake/friction surfaces, support pads, electrical parts or sealed bearings should be lubricated. Remove excess only by the approved method.

Apply the correct family guidance

Protect the laminated top and edge seams from soaking and standing liquid. Confirm compatibility before disinfecting the top, frame or casters. No lubricant belongs on the working surface. Service a folding joint or caster only when the exact model's instructions identify it as a lubrication point.

Check and record before returning to service

Record the date, equipment identity, cleaning/disinfection product, label dilution and contact time, lubricant and approved points treated, findings, corrective work and service references. Check the applicable functions using the approved model instructions. Keep damaged equipment out of use until authorized repair and documented inspection; an entry in the log alone is not operating approval.

Explore the TITAN product families

TITAN Equipment has separate Cots and Tables lines. Links do not imply shared parts or procedures. Request approved instructions with exact model, serial/revision and fitted-control photos.

Equipment & support
Church trucks & drapes · Embalming & dressing tables · Mortuary cots & covers · TITAN product family · Technical support & document requests

Companion review manuals
Church Trucks · Embalming Tables · Mortuary Cots · Standard Folding Table · Cemetery Trucks · Frameless Drapes

Church-truck drape selection & care guide · Review-site copy.

TITAN documentation & support

For model-specific instructions or service: 1-888-792-9315 · service@mymortuarycooler.com · support. Supply order, model, serial/revision and photos.

Rev A · October 30, 2026. Technical review only, not operating instructions, engineering approval or release. Existing warranty and terms apply.

Equipment & training record

Facility / location: _____

Model / serial / revision: _____

Order / delivery date: _____

Original instruction number / revision: _____

Approved accessories / vehicle mount, if applicable: _____

Training record
Record the operator, trainer, exact instruction revision, demonstrated tasks and any restrictions. A signature here does not replace model-specific training.

Date	Operator / trainer	Instruction / task	Sign-off

Inspection & service log

INSPECTION RECORD · Follow the inspection and service intervals in the approved instructions for the exact model. Record actual work and retain supporting records.

Delivery date: _____ Model / serial: _____

Date: _____ Inspector / technician: _____
License / credential (if applicable): _____ Company: _____
Service / reference number: _____

Date: _____ Inspector / technician: _____
License / credential (if applicable): _____ Company: _____
Service / reference number: _____

Date: _____ Inspector / technician: _____
License / credential (if applicable): _____ Company: _____
Service / reference number: _____

Date: _____ Inspector / technician: _____
License / credential (if applicable): _____ Company: _____
Service / reference number: _____

Date: _____ Inspector / technician: _____
License / credential (if applicable): _____ Company: _____
Service / reference number: _____

Date: _____ Inspector / technician: _____
License / credential (if applicable): _____ Company: _____
Service / reference number: _____

WORK PERFORMED, FINDINGS & REFERENCE NOTES

Identify the inspection date; record findings, corrective work, parts and service / invoice references.

Notes